

## AIR MACHINE INSTALLATION & MOUNTING cont.

The air machine can be mounted on a permanent stand, a vault ready stand or a single or dual reel assembly cabinet. All three stands can be mounted to present concrete at the site, or a pad can be poured to mount them. See diagram below for mounting.

### 1020 Stand

